

# BIN MODE

The function of the BIN MODE:

For some cars can not do successfully directly by OBD. Need the BIN MODE to make it completely.

The following is the process for the BIN MODE:

1. Remove and open the cluster, read the EEPROM (24C32 or 24C64) and save, **backup the original dump carefully.**
2. write the dump supplied by smelecom (the address for downloading : <http://www.smelecom.com/sm/download.htm> --[additional data.rar](#)), to the EEPROM, install the chip back to the cluster, also install the cluster back to the car, turn on the ignition, but be carefully , **do not start the car.**
3. Connect the tool to the car, choose **BIN MODE**, the tool will ask you import the original dump backup just now .Then open the dump backup ,and the tool will read out the old km, please verify it. If correct, then input the new km and press OK to continue.
4. Follow the messages make whole process completely.