

BIN MODE-key adaption

The function of the BIN MODE:

For some cars can not do successfully directly by OBD. Need the BIN MODE to make it completely.

The following is the process for the BIN MODE:

1. Remove and open the cluster, read the EEPROM (24C32 or 24C64) and save, **backup the original dump carefully.**
2. write the dump supplied by smelecom (the address for downloading : <http://www.smelecom.com/sm/download.htm> --[additional data.rar](#)), to the EEPROM, install the chip back to the cluster, also install the cluster back to the car, turn on the ignition, but be carefully , **do not start the car.**
3. Connect the tool to the car, choose **BIN MODE**, the tool will ask you import the original dump backup just now .Then open the dump backuped , press OK to continue to complete all the process .